

Roll Forward Skip Auto Tipping Kit Guide

Any standard model of our roll forward skips purchased in or after June 2015 can now be converted into an auto tipping model with the simple inclusion of the auto tipping kit. The kit simply bolts to the existing skip handle assembly, and will allow the user to operate the skip automatically by simply lowering the skip down onto the side of the skip you are tipping into, without having to leave the truck cab and operate the release handle.

To Fit:

Step 1)

Lift the skip and pull the release handle, allowing the skip bucket to roll forward, exposing the handle assembly, as shown left. Fit the 4 castors provided via the castor plates at the front and back of the fork pockets. Swivel castors are fitted at the rear, fixed at the front.

Step 2)

Position the auto tipping bracket assembly between the handle assembly, and bolt in place with the button head bolts provided, ensure spring washers are fitted. Ensure that the paddle is square to the floor when bolted into handle assembly.

Your skip is now fitted with the auto tipping mechanism.

You can at any point, remove the auto tipping kit, or simply cradle it back to remove the auto tipping function. To remove the kit, simply follow the above in reverse. To cradle the kit but keep it attached, please see below. *(Please note; your skip may come with the kit fitted in the cradled position to avoid damage in transit, if so please use the instruction below to enable auto tipping function)*

Step 1)

Remove the securing bolt between the 2 small lugs each side; this will allow the paddle to rotate.

Step 2)

Lift and rotate the paddle in a clockwise direction towards the release handle, until the holes line up and the bolts can be re-fitted to secure the paddle in its new position.

The skip can then be used without the auto tipping paddle in use, with the castors also being removable if desired.

Please ensure bolts are tight and these instructions are followed, failure to do so may result in incorrect operation.

If in doubt, please contact us directly.